

How to use the dishwasher



① Set the tableware face down and place small items such as chopsticks and spoons in the cutlery tray on the left side.

② Place an appropriate amount of detergent in the dishwasher with the measuring spoon provided in the drawer on the left side of the dishwasher.



③ Turn on the power, select a course, and press the start button. Do not open the dishwasher while washing.

④ After washing, remove the dishes. When removing the dishes, be careful not to burn yourself as they may still be warm.

■ For more detailed information, please visit the manufacturer's website.
https://sumai.panasonic.jp/dishwasher/manual/pdf/20130214_torisetsu_NP-45RS6.pdf